

DMX CHANNELS

• 11 Channels mode

• Modalità 11 Canali

CH1: Red CH2: Green CH3: Blue CH4: White CH5: Wood CH6: Amber CH7: Strobe CH8: Dimmer

CH9: Led Fade Time CH10: Rainbow

CH11: Fix White (Balanced White)

• 7 Channels mode

Modalità 7 Canali

CH1: Red CH2: Green CH3: Blue CH4: White CH5: Wood CH6: Amber CH7: Dimmer

6 Channels mode

Modalità 6 Canali

CH1: Red CH2: Green CH3: Blue CH4: White CH5: Wood CH6: Amber





