

DMX CHANNELS / CANALI DMX

• 9 Channels mode • Modalità 9 Canali

CH1: Red
 CH2: Green
 CH3: Blue
 CH4: White
 CH5: Strobe
 CH6: Dimmer
 CH7: Led Fade Time
 CH8: Rainbow
 CH9: Fix White (Balanced White)

• 5 Channels mode • Modalità 5 Canali

CH1: Red
 CH2: Green
 CH3: Blue
 CH4: White
 CH5: Dimmer

• 4 Channels mode • Modalità 4 Canali

CH1: Red
 CH2: Green
 CH3: Blue
 CH4: White

• 9 Channels mode with CYM emulation • Modalità 9 Canali con emulazione CYM

CH1: Cyan
 CH2: Yellow
 CH3: Magenta
 CH4: White
 CH5: Strobe
 CH6: Dimmer
 CH7: Led Fade Time
 CH8: Rainbow
 CH9: Fix White (Balanced White)


• 5 Channels mode with CYM emulation • Modalità 5 Canali con emulazione CYM

CH1: Cyan
 CH2: Yellow
 CH3: Magenta
 CH4: White
 CH5: Dimmer

• 4 Channels mode with CYM emulation • Modalità 4 Canali con emulazione CYM

CH1: Cyan
 CH2: Yellow
 CH3: Magenta
 CH4: White

DMX Channels list 9Ch / Lista dei canali DMX 9Ch



DMX Channels list 5Ch / Lista dei canali DMX 5Ch

| 8bit | FUNCTION | 0 31 63 95 127 159 191 223 255 | | | | | | | | | |
|------|----------|--------------------------------|--|--|--|--|--|--|--|--|--|
| | | [Checkered bar] | | | | | | | | | |
| Ch1 | RED | | | | | | | | | | |
| Ch2 | GREEN | | | | | | | | | | |
| Ch3 | BLUE | | | | | | | | | | |
| Ch4 | WHITE | | | | | | | | | | |
| Ch5 | Dimmer | | | | | | | | | | |

DMX Channels list 4Ch / Lista dei canali DMX 4Ch

| 8bit | FUNCTION | 0 31 63 95 127 159 191 223 255 | | | | | | | | | |
|------|----------|--------------------------------|--|--|--|--|--|--|--|--|--|
| | | [Checkered bar] | | | | | | | | | |
| Ch1 | RED | | | | | | | | | | |
| Ch2 | GREEN | | | | | | | | | | |
| Ch3 | BLUE | | | | | | | | | | |
| Ch4 | WHITE | | | | | | | | | | |

BUILT IN PROGRAMS / LISTA DEI GIOCHI

Here below the list of 12 preset of the fixture.
Qui di seguito la lista dei 12 giochi presenti nell' apparecchio.

| | |
|-----------------------|---|
| Preset 1 | Fixed RED |
| Preset 2 | Fixed GREEN |
| Preset 3 | Fixed BLUE |
| Preset 4 | Fixed WHITE (w) |
| Preset 5 | Fixed MAGENTA |
| Preset 6 | Fixed YELLOW |
| Preset 7 | Fixed CYAN |
| Preset 8 | COLOR CHANGE FAST (Red, Green, Blue, Magenta, Yellow, Cyan, White) Color change no fade |
| Preset 9 | COLOR CHANGE SLOW (Red, Green, Blue, Magenta, Yellow, Cyan, White) Color change with 2,5 sec. fade |
| Preset 10 | RAINBOW SLOW |
| Preset 11 | RAINBOW MID |
| Preset 12 | RAINBOW FAST |
| Preset 13 to | WHITE BALANCE (from cool) |
| Preset 18 | WHITE BALANCE (to warm) |
| Preset 19 to | SIMULATION SODIUM lamps (yellow type) |
| Preset 24 | SIMULATION SODIUM lamps (yellow type) |